



Ohio Lumex Co., Inc.
 9263 Ravenna Rd., Unit A-3
 Twinsburg, OH 44087
 Phone: (330) 405-0837
 Fax: (330) 405-0847
www.ohiolumex.com

Turn - Around Time	
<input checked="" type="checkbox"/>	Standard
<input type="checkbox"/>	2 day rush
Other _____	

Sorbent Trap Analysis Report

Report Number SPP110309 Report

Client Name Super Power Plant

Date 11/3/2009

Contact Name Really Cool Guy rcg@Superpower.com

Phone 123-123-1234

Trap I.D.	Date Analyzed	Scientist	Mass ng Sect.1	Mass ng Sect.2	Mass ng Sect. 3	Spike Level	% Spike Recovery	Break-through %	Days in Stack
39264	11/2/2009	Dr. Qiao He	89	0.6	505	500	101.00%	0.67%	10/12/09-10/19/09
35594	11/2/2009	Dr. Qiao He	95	0.4	499.9	500	99.98%	0.42%	10/12/09-10/19/09
50453	11/2/2009	Dr. Qiao He	857	1.2	495	500	99.00%	0.14%	10/12/09-10/19/09
50327	11/2/2009	Dr. Qiao He	854	0.8	499.1	500	99.82%	0.09%	10/12/09-10/19/09
50239	11/2/2009	Dr. Qiao He	72	0.3	520	500	104.00%	0.42%	10/19/09-10/23/09
50467	11/2/2009	Dr. Qiao He	72	0	504.3	500	100.86%	0.00%	10/19/09-10/23/09
50306	11/2/2009	Dr. Qiao He	72	0.1	504.4	500	100.88%	0.14%	10/23/09-10/28/09
50466	11/2/2009	Dr. Qiao He	74.2	0.2	507.1	500	101.42%	0.27%	10/23/09-10/28/09
12345	11/2/2009	Dr. Qiao He	2706	0.4	2504	2500	100.16%	0.01%	10/12/09-10/19/09
12346	11/2/2009	Dr. Qiao He	2043	0	2432	2500	97.28%	0.00%	10/12/09-10/19/09
12347	11/2/2009	Dr. Qiao He	2242	0	2507	2500	100.28%	0.00%	10/12/09-10/19/09
12348	11/2/2009	Dr. Qiao He	2449	0	2547	2500	101.88%	0.00%	10/12/09-10/19/09
12349	11/2/2009	Dr. Qiao He	2742	1.8	2584	2500	103.36%	0.07%	10/19/09-10/26/09
12350	11/2/2009	Dr. Qiao He	2546	0.4	2432	2500	97.28%	0.02%	10/19/09-10/26/09

Less than .81 ng is considered "< LDL." Which is less than the lowest detection limit.

Calibration Report Available

Variability +/- 10%